Pioneer

CT18M/CY15 Quick Start Guide

Packing Contents

1 X Fingerprint Reader (4GB-F02-R)

1 X M3x9mm screw

1 X Quick Install Guide

Installation

Fingerprint reader can be left mounted or right mounted.



Locate mounting hole on back of machine.



Secure reader to machine with included screw, either on left or right side.

Changing right mount to left mount setup.



Remove locking screw and open the cover.



Move bracket, cable and rubber to the other side then close the cover.



Secure bracket with previously removed screws.



Connect USB A cable to IO port to complete installation.

Packing Contents

1 X Fingerprint Reader (4GB-F02-R)

1 X M3x9mm screw

1 X Quick Install Guide

Installation

Fingerprint reader can be left mounted or right mounted.



Locate mounting hole on back of machine.



Secure reader to machine with included screw, either on left or right side.

Changing right mount to left mount setup.



Remove locking screw and open the cover.



Move bracket, cable and rubber to the other side then close the cover.



Secure bracket with previously removed screws.



Connect USB A cable to IO port to complete installation.

©Pioneer Solution, Inc. 2025

Support@PioneerSolution.com
(909) 468-9757 x2